


MicroStep Motor Driver Rev. 1.1




JP1	STEP
NDNE	1/8_EXT
1-4	1/16
1-3	1/32
1-3,2-4	1/64


JP2	FC
1-3,2-4	DISABLE
NDNE	EXT

JP3	COM
SHORT	TTL
OPEN	RS232

SV GND TX RX ECUW CW FCW FCCW CLK DIR RESO REBI



MicroStep Motor Driver Rev. 1.1



A